???? ?? ??????::

133-66

























The Sandberg USB DVD Drive enables you to burn and read CDs and DVDs. This drive is the perfect addition to a computer without a CD drive or DVD burner. The drive is powered from your computer's USB port so that you can use it on the go without having to locate a power point. Also works well as a mobile DVD player for your laptop. No software installation is required, enabling you to use the drive instantly.



## Sandberg USB DVD Drive






Write speeds: CD-R at 24 x speed CD-RW at 8 x speed DVD-R at 8 x speed DVD-RW at 8 x speed DVD±R DL x 6 speed DVD-RAM x 5 speed

Read speeds: CD-ROM at 24 x speed DVD-ROM at 24 x speed Reads audio CDs

Disc format: MiniDVD/CD: 3"







## **\$** ????????? ?? ????????

1 Sandberg USB Mini DVD Burner		
1 USB data transfer cable 0.65 metres		
1 USB power cable 0.65 metres		
1 User guide		
??? ?????: https://sandberg.mk/mt/manual/133-66		



	????????	?????
?????? (cm)	13.70	18.20
?????? (cm)	13.30	15.00
???????? (cm)	1.80	2.60
?????? (g)	266.00	400.00

Q<sub>O</sub>

www.sandberg.world/product/USB-Mini-DVD-Burner



?????: