

Sandberg®

Speaker Radio FM+BT Recharge

???? ?? ??????..




421-18

Sandberg®
ACTIVE

EAN:



5705730421181




Sandberg Speaker Radio FM+BT Recharge ?????????? ?????????? FM ????? ?? ????????? Bluetooth

???????? ?? ???? ????????? ? ?????????? ?????????? ?? ????????????? ?????????? ??? ?? ?????, ????? ????????? ?? ????????? ?? ????????? ? ????? ????
??? ????? ????????? ? ????????????? ?????????? ?? ??????. ????????? ? ?? ????????????? ?????????, ??? ? ?? ???? ????????? ???? ??? ????????????? ?? F
???? ?? ???? ?????????.




?????? ??????????????
 www.sandberg.mk

Sandberg Speaker Radio FM+BT Recharge




FM Frequency range: 87,5-108 MHz
 Speaker output: 5W
 USB-C Input (charging by included USB-A to USB-C cable)
 Charge time: 3-4 hours
 Playing time: up to 15 hours
 Built-in display
 Battery capacity: 1200 mAh
 Bluetooth: 5.0
 MP3/USB/TF-Card
 3.5mm minijack audio output



1 Sandberg Speaker Radio FM+BT Recharge
 1 Quick guide
 1 USB-A to USB-C charge cable

??? ????: <https://sandberg.mk/mt/manual/421-18>



	????????	?????
?????? (cm)	7.25	15.00
?????? (cm)	11.80	9.00
???????? (cm)	3.35	4.10
?????? (g)	260.00	280.00



????????:
www.sandberg.world/product/speaker-radio-fmbt-recharge



?????: